

Vehicle Pre-Trip Inspection Criteria

Method Legend:

Visual = V

Manual = M

Audible = A

Not Applicable = N/A

Outside Checks

Item	Method	Proper Condition	Acceptable Condition	Out of Service Condition
Manitoba Safety Inspection Decal	V	N/A	N/A	Missing; unreadable; expired
				Two stars and/or chips greater than 25mm (1 inch) or any intersecting
Windshields	V	No damage; clear vision	Star or chip less than 25mm (1 inch)	cracks in the driver's vision or wiper sweep area
Mirrors	V	No damage; secure	Insecure	Obstructed; fails to provide a clear view
Side Windows	V	No damage; clear vision	Leaking; cracked	Obstructing vision; shattered
Bumpers - Front & Rear	V; M	No damage; secure	Insecure; bolt missing	Missing; damaged; outside of body lines
Rear Emergency Door (if applicable)	Method	Opens/closes	Buzzer not functioning; door hinges stiff to open	Door does not open/close securely
				Flat tire; tire tread depth less than wear limit; tire in contact with another tire or any vehicle component other than mud flap; tire marked "not for
Tiree	\/· NA	Annoor proper	Demograd tread or eidewally tire looking	
Tires	V; M	Appear proper	Damaged tread or sidewall; tire leaking	highway"; tire has exposed cords in the tread/outer sidewall area Wheel has loose/missing/ineffective fastener; damaged/cracked/broken
				wheel/rim or attaching part; evidence of imminent wheel/hub or bearing
Wheel Live & Festerers	\/. NA			
Wheel Hub & Fasteners	V; M	Appear proper	Hub oil below minimum level (with sight glass); wheel seal seepage	failure
				Shock absorber missing/damaged; deflated airbag; cracked/broken main
				spring leaf or more than one broken spring leaf; part of spring
			Seepage of shack absorber; air leak in air suspension system; suspension	leaf/suspension missing/shifted out of place or in contact with another
Suspension	V	No noticeable sag/lean	fastener loose/missing/broken	vehicle component; loose U-bolt
				Audible warning operating; damaged part(s) of air system causing
Air System	V; A	No damage; secure		problems with air build up
				Visibly shifter/cracked/collapsing/sagging frame member(s); any exterior
Vehicle Body & Frame	V; M	No damage; secure		body panel damaged/deteriorated so that it causes a hazard to others
	.,			Fails to adequately provide enough fluid to clear driver's field of vision in
Windshield Washer Level	V	Adequate level	N/A	area swept by driver's side wiper
			Coolant level below add mark; coolant visible in reservoir; drive belt(s) in	
Coolant Level & Radiator/Belts	V; M	Adequate level; drive belt(s) in place	place	Leaks; no coolant visible in reservoir; drive belt(s) missing
Engine Oil Level		Operating level	Oil level at "add" mark on dipstick	Oil level below "add" mark on dipstick
Fuel System		No damage/leaks	N/A	Missing fuel tank cap; insecure fuel tank; dripping fuel leak
License Plate		Valid; Secure	Loose	Invalid; missing

Hydraulic Brake System (in driver's seat with ignition off, depress brake pedal)

Item	Method Proper Condition	Acceptable Condition	Out of Service Condition
			Brake boost/power assist inoperative; brake fluid leak; brake pedal
			fade/insufficient brake pedal reserve; brake fluid reservoir less than one-
Hydraulic Brake System	V; M; A Functioning	Brake fluid level below indicated minimum level	quarter full

Starting the Engine

Method	Proper Condition	Acceptable Condition	Out of Service Condition		
V	No warning light	Warning light on (no ABS brakes)	N/a		
V; A	No warning light or buzzer	N/A	Activated warning device		
			Accelerator sticking and engine fails to return to idle; activated vehicle		
V; M; A	Pedals/gauges functioning properly	Instruments inaccurate/no freeplay in clutch (if applicable)	chassis warning device; clutch fails to release		
V; M	Engine starts	Engine starts in gear	N/A		
_	V V; A V; M; A	V No warning light V; A No warning light or buzzer V; M; A Pedals/gauges functioning properly	V No warning light Warning light on (no ABS brakes) V; A No warning light or buzzer N/A V; M; A Pedals/gauges functioning properly Instruments inaccurate/no freeplay in clutch (if applicable)		

With Engine Running, Check from Driver's Seat

Item	Method	Proper Condition	Acceptable Condition	Out of Service Condition
Mirrors	V; M	Properly Adjusted	Fail to provide required view to driver due to cracking/maladjustment	Mirror missing/broken and unable to provide view to the rear
				Steering wheel insecure/does not respond normally; steering wheel lash
Steering	V; M	Functioning	Steering wheel lash (free-play) greater than normal	(free-play) exceeds prescribed limit
Horn	M; A	Functioning	No operative horn	N/A
				Defroster motor fails to operate in all selected positions; airflow over
Defroster/Heater Operation	M; A	Functioning	Control/system failure	intended area not present
				When necessary for prevailing weather conditions, wiper or washer fails
			Control/system malfunction; wiper blade damaged/missing or fails to	to adequately clear the driver's field of vision in area swept by driver's
Windshield Wiper/Washer	M; A	Functioning	adequately clear driver's field of vision	side wiper
Park Brake	V; M	Functioning	Releases but light stays on	Park brake won't release
Service Door Control	V; M	Operates properly	Operates unevenly	Door fails to open or close securely
Interior & Stepwell Lights	V; M	Operates properly	No more than one lamp not functioning	N/A

Vehicle Pre-Trip Inspection Criteria

Method Legend: Visual = V Manual = M Audible = A Not Applicable = N/A

Look Inside the Vehicle

Item	Method	Proper Condition	Acceptable Condition	Out of Service Condition
				Seatbelt/tehe3rb belt insecure/missing or malfunctions; fails to maintain
Driver's Seat & Seat Belt	М	Operate properly	Seat damaged/ripped	selected adjustment
				Any seat or attaching fixture with a defect that may constitute a hazard to
Passenger Seats & Seat Belts (if applicable)	V; M	No damage; secure	Seat(s) damaged/ripped (move passengers if necessary)	any person
			Stanchion padding damaged; damaged steps/slipping hazard;	Interior body panels damaged/present a hazard to any person; passenger
Passenger Compartment	V; M	No damage	insecure/damaged overhead compartment	seat insecure
Emergency Exits (i.e. rear door; side windows; roof top)	V; M; A	Function properly	Buzzer inoperative	Emergency exits fail to function as intended
Fire Extinguisher	V; M	Secure; charged	Insecure	Missing/discharged (reading in gauge)
First Aid Kit	V; M	Secure; sealed	Insecure; seal broken	Missing
Fire Axe or Crow Bar	V; M	Secure	Insecure	Missing
Triangular Reflectors	V; M	Secure	Insecure	Missing/broken
Wheelchair Door & Latches	V; M; A	Opens/closes	Buzzer not functioning; door hinges stiff to open	Door fails to open/close securely
				Lift safety devices fail to function as intended; lift does not complete
Wheelchair Lift	V; M	Function properly	Wheelchair lift has uneven movement; lift operates slowly	cycle; interlock system fails to activate/release as intended
Wheelchair Restraints	V; M	Function properly	N/A	Malfunction; absence of required passenger or mobility device restraints
Cargo Securement	V; M	Secure	Insecure	Failure/malfunction/deterioration of required items to be secured

Outside Checks Required Before Driving Away

Item	Method	Proper Condition	Acceptable Condition	Out of Service Condition
Loading Lights	V	Functioning	One of eight lamps inoperative; cracked/fogged lens	Two or more lamps inoperative; lamps do not alternate
Turn Signals	V	Functioning	Front exterior lamps inoperative; cracked/fogged lens	Does not have at least one left and one right rear turn signal lamp
Daytime Running Lights	V	Functioning	Not functioning as intended	Low beam headlights not functioning
Headlights	V	Functioning	At least one low beam headlight; cracked/fogged lens	Failure of both low beam headlights
Stop Lights	V	Functioning	One of four lamps inoperative; cracked/fogged lens	Two or more lamps inoperative
Tail Lights	V	Functioning	One of four lamps inoperative; cracked/fogged lens	Two or more lamps inoperative
Marker/Clearance Lights	V	Functioning	Up to three lamps inoperative; cracked/fogged lens	More than three lamps inoperative
Back-Up Lights	V	Functioning	At least one lamp operative; cracked/fogged lens	More than one lamp inoperative
Hazard Warning Lamps	V	Functioning	Both front hazard lights inoperative; cracked/fogged lens	Both rear hazard lamps inoperative
			Exhaust leak except as described in Out of Service Condition column;	
Exhaust System	V	Functioning	loose components	Exhaust leak that causes exhaust gas to enter the occupant compartment
Strobe Light	V	Functioning	Strobe light permit missing/illegible; strobe light inoperative	N/A